

# Premiere PS-500-RV Installation Instructions

## PS-500-RV Ultrafiltration System Operating Conditions

Operating temperature	Min 40°F (4.4°C) / Max 100°F (37.8°C)
Operating pressure	Min 30 psi (2.11 kg/cm <sup>2</sup> ) / Max 85 psi (6.0 kg/cm <sup>2</sup> ) A pressure regulator is required for pressures over 75 psi
pH parameters	Min 6 / Max 10
Flow rate	4 GPM @ 60 psi (dependent on water pressure and water temperature)
Maintenance Schedule	<b>Flush ultrafiltration (UF) membrane at least once per month.</b> Flushing the membrane more frequently may be required depending on your water conditions. Read more on page 2. <b>Replace UF membrane every 3 - 5 years.</b>

## Pre-Installation Information

- This system installs on the incoming water line, and before any other water treatment such as a water softener or water heater.
- There three ports that require connection: inlet, outlet, and flush (membrane backflush).
- During the membrane backflush, approximately 1-2 gallons of water may be used. (Instructions for how to backflush the membrane are on page 2). Therefore this system should be installed in a location so that the water from this drains into a bucket, or you can plumb the flush port for irrigation use.
- Please ensure this system is covered and protected - avoid direct sunlight, freezing temperatures, etc.. Don't install it where it could experience any rough contact. If you are not mounting the system, some users put this system in a plastic tub or laundry basket.
- This system becomes very heavy when it's filled with water. If you plan to mount the system using a bracket and screws, ensure the surface you are attaching it to is reinforced and able to support at least 15 pounds. Also, leave at least 3" below the housing so that you can easily unscrew the filter housing and replace the membrane when it's time.
- A pressure regulator (not included) is required for pressures over 75 psi. They are available at most home improvement stores. A pressure regulator is installed before water comes into this system.



Premiere Sales | (800) 817-6306 | sales@premieresales.com

# Premiere PS-500-RV Installation Instructions

## Installing the PS-500-RV Ultrafiltration System

Shut off the main water supply. Relieve pressure in the line by turning on a cold water tap/faucet downstream of where the system is to be installed.

Locate the three double o-ring fittings and insert each of these fittings into the inlet, outlet, and flush ports on the head of the system. Push the fitting in until it comes to a secure stop in the port.

Locate the elbow with check valve attached. The check valve prevents the back flow of water when the system is being flushed so that the rinse water goes out the flush port. Push this elbow into the inlet port (you may need to wiggle it in) until it comes to a stop.

There are three metal clips included - one metal clip per port. Use one of the metal clips to secure the elbow in place. Put the clip into the two holes above the port. It drops down to secure the fitting. You may need to gently wiggle or slightly tap the clip. Make sure that the clip is flat against the filter head.

There are two elbows with ball valve and hose connector attached. One elbow goes into the inlet port and the other into the flush port. Like above, push the elbow into the outlet or flush port (you may need to wiggle it in) until it comes to a stop. Install the clip to secure each elbow.

Once all three ports in the head are securely connected and the clips are in place, the system is ready to connect to your hose or plumbing.

After the system is fully connected to your hose or plumbing, slowly turn back on the main water supply. Check all the connections on the PS-500-RV and these connections to your hose or plumbing to ensure that there are no leaks.

Open a cold water tap/faucet downstream of where the system is installed. Continue to leave open until any air sputtering stops and that water is running clear, then turn off the tap/faucet. This may take up to 10 minutes.

Check all the connections again to make sure there are no leaks.

## Important Maintenance Information

### How to Flush the PS-500-RV System

Leave incoming water on. Close the outlet valve on the system and open the flush valve on the ultrafiltration membrane housing. Leave open for about 20 seconds. This will release about 1 - 2 gallons of water out of the flush port.

### When to Flush the PS-500-RV System

The ultrafiltration membrane should be flushed on a regular basis for longest membrane life. How often you flush the membrane will depend on the water conditions and usage. The ultrafiltration membrane should be flushed at least once per month, and some users may find they need to flush it a few times a month, weekly, or even daily.

In general, you will know it is time to flush the membrane when there is a consistent, noticeable drop in water pressure.

